

Front Wheel Assembly

Place fork onto the wheel axle.
Do not loosen axle nuts.



Make sure tire is facing the right
way: see drive arrow on inside tire.



Front Wheel Assembly Continued

Run quick-release skewer through axle and tighten snugly, so that the lever clamps firmly onto the fork arm.

